

TIPS FOR

MAXIMUM FLOAT LIFE

- Use ULTRA HI-FLOAT
- Use the recommended clip on the pump dispenser
- Inflate balloons fully
- Ideal temperature for balloons is 72° to 80° F
- Run the heater or air-conditioner to lower humidity
- Keep HI-FLOAT treated balloons out of direct sunlight
- Use HI-FLOAT Balloon Transport Bags



How Many Balloons Will a Bottle Treat?

Balloon Size	ULTRA HI-FLOAT 96 oz.	ULTRA HI-FLOAT 24 oz.	ULTRA HI-FLOAT pint
11 inches	567	141	100
14 inches	405	101	67
16 inches	216	54	36

Clip Sizes

Balloon Size	ULTRA HI-FLOAT
9 inches	purple
11 inches with 60/40 inflator	purple
11 inches with valve	purple
11 inches	orange
14 inches	2 strokes orange
16 inches	2 strokes grey
24 inches	3 strokes grey
30 inches	2 strokes no clip
36 inches	3 strokes no clip
40 inches	4 strokes no clip
48 inches	3/4 cup (add through funnel)
60 inches	1 1/2 cup (add through funnel)



HI-FLOAT®

Balloon Treatment

www.hi-float.com
info@hi-float.com
1-800-57FLOAT
(502) 244-0984

Latex Balloon Size	Latex Balloon Type	Balloons Per 242 Helium Tank	Average Flying Time Helium Only	Average Flying Time Helium and ULTRA HI-FLOAT
9" with valve	STANDARD COLORS	880	6 hrs.	3-10 days
9"	STANDARD COLORS	880	10-15 hrs.	4-14 days
11" with valve	STANDARD COLORS	485	14-18 hrs.	5-21 days
11" with 60/40 inflator	STANDARD COLORS	800	12-18 hrs.	3-10 days
11"	STANDARD COLORS	485	12-24 hrs.	1-4 weeks
11"	METALLIC & PEARLIZED	485	12-24 hrs.	1-3 weeks
14"	ROUND	240	26-30 hrs.	2-5 weeks
16"	ROUND	180	30+ hrs.	3-7 weeks
18"	ROUND	130	36+ hrs.	3-8 weeks
17"	HEART	268	14 hrs.	3-8 days
16"	GEO DONUT®	340	22-26 hrs.	4-12 days
16"	GEO BLOSSOM®	400	18-24 hrs.	3-10 days
24"	ROUND	50	2-4 days	4-10 weeks
3'	GIANT	15	3-5 days	6-20 weeks